

AP00.20-U-1208R SERVICE SHEET for Mercedes-Benz Maintenance System (USA) 1.3.05

MODEL 251

Light Truck Model Year 2006



Customer:		Repair order numb	per:
First visit	at 1,000 - 3,000 miles	Performed	YES NO
Tire Rotation	Performed in accordance with the tire manufacturer's recommended intervals	Tires rotated	YES NO
Tire Inspection	Inspect tires for damage and correct tire inflation pressure	Tires inspected	YES NO
Current mileage reading:			r:
Service work to be performed as advised by Completion date: service advisor:		Confirm work below:	k has been performed by signing

i

US Service 4 through US Service 20 apply to "Additional work" items only.

Vehicle determines need for US Service 3 (Engine oil and filter change) as well as US Service 1 or US Service 2

Perform each service as described.

US Service		first at 13,000 mi or 1 year;	after first every 26,000 mi or 2 years	
1	US Service	first at 26,000 mi or 2 years;	after first every 26,000 mi or 2 years	
↓	2 .l.		Not OK ↓	
6		Interior	v	
	0	Reset service indicator in instrument cluster		AP00.20-P-0042RT
		Function test		
	0	Battery, check battery condition using "Midtronics MCR 717" tester.		AP54.10-U-5453A
		Attach Midtronics MCR 717 Test Report print out here.		
	0	Check parking brake (function test only)		AP42.00-P-4290RT
	0	Horn, warning/indicator lamps, illumination and interior lighting		
	0	Windshield wipers, windshield washer system		AP82.30-P-8252RT
	0	Headlamp cleaning system, where applicable		
	0	Check seat belts and buckles for signs of external damage and proper function		AP91.40-P-9150RT
		Wheels, brakes		
† _□	• 0	Inspect tires for damage and splits, measure tread depth, record in mm: LF RF LR RR outside		AP40.10-P-4051RT
	0	inside		AP40.10-P-4050RT
	O	Check front brake pads for lining thickness, (remove right front wheel)		AP42.10-P-4251RT
	0	Check front/rear brake pads for lining thickness		AP42.10-P-4251RT
	0	Check condition/thickness of front/rear brake discs		AP42.10-P-4251RT
	0	Correct tire inflation pressure		
		Underside of vehicle		
·	. 0	Leakage - Major components Check for chafe marks, line routing, damaged components i In the event of leakage, determine cause and perform repair via separate work order		AP00.20-P-0053RT
	0	Check front axle ball joints for play, check rubber boots		AP33.20-P-3353RT
	0	Check rear axle ball joints for play, check rubber boots		AP35.20-P-3555RT
	0	Inspect play of tie rod and and drag link joints, inspect rubber boots		AP46.00-P-4653RT
	0	Inspect condition of flexible discs		

US Service	US Serv	/ice			Not OK	
1		2 .l.			\downarrow	
io		<u> </u>	Vehicle front/rear		•	
		0	Check wiper blade condition			AP82.30-P-8253G
		0	Check and correct headlamp setting			AP82.10-P-8260RT
	7		Engine compartment			
		0	Leakage - Major components Check for chafe marks, line routing, damaged components i In the event of leakage, determine cause and perform repair via separate work order			AP00.20-P-0053RT
		0	Check catch, safety catch and hinges on engine hood for proper operation.			AP88.40-P-8851RT
		0	Check condition of poly-V-belt			
			Engine 113:			AP13.22-P-1351RT
			Engine 272:			AP13.22-P-1351RTC
			Check fluid level, correct as required ilf there is a loss of fluid, determine cause and perform repair via separate work order			
		0	Brake system			AP42.10-P-4210RT
		0	Power steering			AP46.00-P-4611RT
		0	Windshield washer system (incl. summer/winter cleanser)			AP82.35-P-8210RT
			Additional Work			
Co	mpleted	ΙX			Not OK	
		\			\	
US Ser	rvice 3		every 13,000 mi or 1 year:			
		_	Engine compartment	Funda 442		A D40 00 D 0404 DT
		Ш	Engine - oil and filter change	Engine 113: Engine 272:		AP18.00-P-0101RT
IIS Sou	rvice 4		every 2 years:	Erigine 272.		AP18.00-P-0101RTC
03 361			Check bodywork for paint work damage		П	AP98.00-P-9850RT
		ш	by service advisor			AF96.00-F-9630K1
			Underside of vehicle			
			Chassis and load-bearing body components: Check for damage and corrosion by service advisor			AP00.20-P-0090RT
			Engine compartment			
			Replace brake fluid			AP42.00-P-4280RT
US Ser	rvice 5		every 26,000 mi or 2 years:			
			Passenger compartment			
			Replace combination filter			AP83.00-P-8384RT
US Servic	e 6 and 7	7	not applicable			

Completed 2		Not	
1			ļ.
US Service 8	every 52,000 mi or 4 years:		
	Engine compartment		
	Replace engine air-cleaner insert	Engine 113:	AP09.10-P-0980RT
		Engine 272:	AP09.10-P-0980RTC
US Service 9	not applicable		
US Service 10	every 13,000 mi or 1 year:		
	Panorama sliding roof: Clean and lubricate guide mechanism		AP77.20-P-7732RT
US Service 11	every 65,000 mi or 5 years:		
	Passenger compartment		
	Replace fuel filter		AP47.20-P-0780RT
US Service 12 Engine 113	every 91,000 mi or 5 years: Engine compartment		
	Replace spark plugs		AP15.10-P-1580RT
US Service 12 Engine 272	every 78,000 mi or 5 years: Engine compartment		
	Replace spark plugs		AP15.10-P-1580RTC
US Service 13	every 143,000 mi or 15 years:		
	Engine compartment		
	Replace coolant	Engine 113:	AP20.00-P-2080RT
		Engine 272:	AP20.00-P-2080RTC
US Service 14-19	not applicable		
US Service 20	once at 39,000 mi:		
	Underside of vehicle		
	Automatic transmission - oil and filter		AP27.00-P-2702W
	change		
	Vehicle over 143,000 mi:		
	Check if all fluid levels and changes are updated		
⊯AP □	Transmission	I	
⊯AP □] Rear axle	J	
F AP □] Front axle		
F AP □] Transfer case		
	Check if air, fuel, ventilation filters are updated		
l AP □] Engine air filter	1	
⊯AP □	Fuel filter	I	
 ⊯AP □	Combination filter	Ì	_
	Check integrity of engine, mechanical co- monents		
⊯ AP □	Perform compression test (hot and cold) Refer to BE01.00-Z-9999AZ	1	
F AP □	Perform leak down test (hot and cold)		AP00.20-P-0053RT
⊯AP □	Check spark plugs	1	
⊯ AP □		I	

	Completed \boxtimes		Not OK
	1		\downarrow
		Check damaged / worn drivetrain parts	
F≆AP		Front wheel bearing play	
F≆AP		Rear wheel bearing play	
F≆AP		Axles joint play	
F≆AP		Flexible discs	
F≆AP		Tie rod and drag link joints	