

AP00.20-U-1208ID	SERVICE SHEET for Mercedes-Benz Maintenance System (USA)	28.3.07
------------------	--	---------

MODEL 221

except AMG models

Passenger cars Model Year 2008





Customer: Re		Repair order numb	Repair order number:		
First visit	at 1,000 - 3,000 miles	Performed	YES	NO	
Tire Rotation (non staggered width wheel setup only)	Performed in accordance with the tire manufacturer's recommended intervals	Tires rotated	YES	NO	
Tire Inspection (staggered and non- staggered width wheel setup)	Inspect tires for damage and correct tire inflation pressure	Tires inspected	YES	NO	
Current mileage reading:		Oil grade/viscosity	:		
Additional notes:					
Service work to be performed service advisor:	as advised by Completion date:	Confirm work below:	t has been perform	ed by signing	

i

US Service 4 through US Service 20 apply to "Additional work" items only.

Vehicle determines need for US Service 3 (Engine oil and filter change) as well as US Service 1 or US Service 2.

Perform each service as described.

US Service		first at 13,000 mi or 1 year;	after first every 26,000 mi or 2 years	
1	US Service	first at 26,000 mi or 2 years;	after first every 26,000 mi or 2 years	
↓	2 .l.		Not OK ↓	
6A		Interior	•	
	0	Reset service indicator in instrument cluster		AP00.20-P-0042SX
	0	Night View Assist camera - clean		AP54.30-P-5431SX
		windshield behind the camera cover		
		Function test		
_	0	Check parking brake (function test only)		
	0	Horn		
	0	Warning/indicator lamps, illumination and interior lighting		AP54.30-P-5452C
	0	Windshield wipers, windshield washer system, headlamp cleaning system		AP82.30-P-8252SX
	0	Check seat belts and buckles for signs of external damage and proper function		AP91.40-P-9150SX
	>	Wheels, brakes		
	0	Inspect tires for damage and splits, measure tread depth, enter in mm:		AP40.10-P-4051SX
		LF RF LR RR		
		outside center		
		inside		
	0	Check thickness of brake pads, front and rear		AP42.10-P-4253A
	0	Correct tire inflation pressure and enter in		
		bar or psi. LF RF LR RR		
		bar/psi:		
		Underside of vehicle		
	. 0	Leakage - Major components Check for chafe marks, line routing, dama-		AP00.20-P-0053SX
		ged components		
		i In the event of leakage, determine cause and perform repair via separate work or-		
		der		
	0	Check front axle ball joints for play, check rubber boots		AP33.20-P-3353SX
	0	Inspect condition of driveshaft flexible discs		AP41.10-P-4152SX
	0	Inspect play of tie rod and drag link joints, inspect rubber boots		AP46.00-P-4653SX
i Part	*	Vehicle front/rear		
	0	Check and correct headlamp setting		AP82.10-P-8260SX
	0	Check wiper blade condition		AP82.30-P-8253SX

US Service	US Servic		Not OK	
1 ↓		2	↓	
*		Trunk		
COLL				
		Check auxiliary battery condition using "Midtronics MCR 717" Tester. Attach "Midtronics MCR 717" Test Report print out here.		
	C	Correct inflation pressure of spare tire and enter in bar or psi. bar/psi:		
	C	Check trunk lighting		
		Engine compartment		
	C	Leakage - Major components Check for chafe marks, line routing, damaged components in the event of leakage, determine cause and perform repair via separate work order		AP00.20-P-00535X
	C	Check catch, safety catch and hinges on engine hood for proper operation.		AP88.40-P-8851SX
		Check condition of poly-V-belt		
		Check fluid level, correct as required ilf there is a loss of fluid, determine cause and perform repair via separate work order		
	C	Starter battery, check and correct fluid level		AP54.10-P-5410SX
	C	Check starter battery condition using "Mid- tronics MCR 717" Tester. Attach "Midtronics MCR 717" Test Report print out here.		
		Brake system		AP42.10-P-4210SX
		Power steering		AP46.00-P-4611SX
		Active Body Control (Code 487)		AP32.50-P-3213SX
	C	Windshield washer system (incl. summer/winter cleanser)		AP82.35-P-8210SX
		Additional Work		
Co	ompleted 2		Not OK ↓	
US Se	rvice 3	every 13,000 mi or 1 year:		
		Engine compartment		
		Engine - oil and filter change		AP18.00-P-0101SX
US Se	rvice 4	every 2 years:		
		Check bodywork for paint work damage by service advisor		AP98.00-P-9850SX
		Underside of vehicle		
		Chassis and load-bearing body components: Check for damage and corrosion by service advisor		AP00.20-P-0090SX
		Engine compartment		
		Replace brake fluid		AP42.00-P-4280SX

Completed ⊠				Not OK	
↓ 	25 000			<u> </u>	
US Service 5	every 26,000 mi or 2 years:				
	Passenger compartment				4 DO2 00 D 02046V
⊔ 	Replace combination filter				AP83.00-P-8384SX
US Service 6 & 7	not applicable				
US Service 8	every 52,000 mi or 4 years:				
	Engine compartment				
Ш	Replace engine air-cleaner insert				AP09.10-P-0980SX
US Service 9	every 5 years:				
_	Passenger compartment				
	Tilting/sliding roof: Clean slide rail and de block	sli-			AP77.20-P-7731SX
US Service 10	every 3 years:				
	Passenger compartment				
	Panoramic sliding roof - clean and lubric quide mechanism	cate			AP77.20-P-7732SX
US Service 11	every 143,000 mi or 15 years:				
	Passenger compartment				
	Replace fuel filter				AP47.20-P-0780SX
US Service 12	every 91,000 mi or 5 years:				
Engine 273	Engine compartment				
	Replace spark plugs				AP15.10-P-1580SX
US Service 13	every 143,000 mi or 15 years:				
	Engine compartment				
	Replace coolant				AP20.00-P-2080SX
US Service 14 - 19	not applicable				
US Service 20	once at 39,000 mi: Underside of vehicle				
	Automatic transmission - oil and filter				AP27.00-P-2702W
_	change				
Completed ⊠ ↓	Perfo	rm:	Yes ↓	Not OK ↓	
•	Vehicle over 143,000 mi:		<u>*</u>		
	Check if all fluid levels and changes are	un-			
	dated	чp			
⊯ AP □	Transmission				
⊯ AP □	Rear axle				
	Check if air, fuel, ventilation filters are u	ıp-			
 ⊯AP □	Engine air filter				
 ⊯FAP □	Fuel filter				
I S AP □	Combination filter				
				_	

	Completed 🗵	Perform:	Yes	Not OK	
	↓		\downarrow	↓	
		Check integrity of engine, mechanical comonents			
₩ÃΡ		Perform compression test (hot and cold) Refer to BE01.00-Z-9999AZ			
β≆AP		Perform leak down test (hot and cold)			AP00.20-P-0053SX
β≅AP		Check spark plugs			
₩ÃΡ		Exhaust system hangers and leaks			
		Check damaged / worn drivetrain parts			
β≆AP		Front wheel bearing play			
₩ÃΡ		Rear wheel bearing play			
β≅AP		Axle joint play			
₩≅AP		Driveshaft flexible discs			
₩ÃΡ		Tie rod and drag link joints			