

AP00.20-U-1208V SERVICE SHEET for Mercedes-Benz Maintenance System (USA) 18.8.04

**MODEL 171** 

except AMG models

## Passenger cars Model Year 2005



Customer:		Repair order number:		
First visit	at 1,000 - 3,000 miles	Performed	YES NO	
Tire Rotation (non staggered width wheel setup only)	Performed in accordance with the tire manufacturer's recommended intervals	Tires rotated	YES NO	
Tire Inspection (staggered and non- staggered width wheel setup)	Inspect tires for damage and correct tire inflation pressure	Tires inspected	YES NO	
Current mileage reading: Additional notes:			y:	
Service work to be performed as advised by service advisor:  Completion date: Confirm work has been performed by signing below:				

i

 $\label{thm:conditional} {\it US Service 4 through US Service 13 apply to "Additional work" items only.}$ 

Vehicle determines need for US Service 3 (Engine oil and filter change) as well as US Service 1 or US Service 2

(formerly A-Service and B-Service respectively).

Perform service necessary as indicated in display of instrument cluster only.

Perform each service as described.

US Service		first at 13,000 mi or 1 year;	after first every 26,000 mi or 2 years	
1	US Service	first at 26,000 mi or 2 years;	after first every 26,000 mi or 2 years	
,	2		Not OK ↓	
· ·		Engine compartment	•	
	0	Leakage - Major components Check for chafe marks, line routing, damaged components  iln the event of leakage, determine cause and perform repair via separate work order		AP00.20-P-0053V
	0	Check catch and safety catch and hinges on engine hood for proper operation.		AP88.40-P-8851V
	0	Check battery condition using "Midtronics MCR 717" Tester. Attach Midtronics MCR 717 Test Report print out here.		AP54.10-U-5453A
	0	,		AP13.22-P-1351VA
		Check fluid level, correct as required  i If there is a loss of fluid, determine cause and perform repair via separate work order		
	0	Brake system		AP42.10-P-4210V
	0	Power steering		AP46.00-P-4611V
	0	Windshield washer system (incl. summer/winter cleanser)		AP82.35-P-8210N
60		Interior		
	0	Reset service indicator in instrument cluster		AP00.20-P-0042V
	_	Function test	_	
_	0	Check parking brake (function test only)		AP42.00-P-4290V
	O	Warning/indicator lamps, illumination and interior lighting		
	0	Windshield washer system		AP82.30-P-8252V
	0	Headlamp cleaning system		
	0	Check seat belts and buckles for signs of external damage and proper function		AP91.40-P-9150V
		Wheels, brakes		
Ť 🗆	Ť	Check front brake pads for lining thickness (remove right front wheel)		AP42.10-P-4251V
	0	Check front/rear brake pads for lining thickness		AP42.10-P-4251V
	0	Check condition/thickness of front/rear brake discs		AP42.10-P-4251V
	0	Inspect tires for damage and splits, measure tread depth, enter in mm:  LF RF LR RR  outside  center inside		AP40.10-P-4051Z
	0	Correct tire inflation pressure (incl. spare tire)		

US Service	US Serv			Not OK	
1 .l.		<b>2</b>		$\downarrow$	
•	7		Underside of vehicle	<b>▼</b>	
EO	20)				
<b>†</b> †	Ť	0	Leakage - Major components		AP00.20-P-0053V
			Check for chafe marks, line routing, damaged components		
			i In the event of leakage, determine cau-		
			se and perform repair via separate work or- der		
		0	Check front axle ball joints for play, check	П	AP33.20-P-3353V
		•	rubber boots	_	
		0	Inspect condition of flexible discs		AP41.10-P-4152V
		0	Inspect play of tie rod and and drag link joints, inspect rubber boots		AP46.00-P-4653V
606			Trunk		
		0	Check trunk lighting		
		0	Check TIREFIT tire sealant expiration date		AP40.10-P-4054R
†	*		Vehicle front/rear		
	400				
		0	Check headlamp range adjustment motor (not for xenon headlamps)		
		$\circ$	Check and correct headlamp setting		AP82.10-P-8260V
Co	mpleted			Not OK	
		↓   		Not OK ↓	
	ompleted		every 13,000 mi or 1 year:		
		<u> </u>	Engine compartment	<b>↓</b>	AD40.00 D 0404VA
US Sei	rvice 3		Engine compartment  Engine - oil and filter change		AP18.00-P-0101VA
US Sei		<u>↓</u>	Engine compartment  Engine - oil and filter change  every 2 years:	<b>↓</b>	
US Sei	rvice 3	<u> </u>	Engine compartment  Engine - oil and filter change	<b>↓</b>	AP18.00-P-0101VA AP98.00-P-9850BA
US Sei	rvice 3	<u>↓</u>	Engine compartment  Engine - oil and filter change  every 2 years:  Check bodywork for paint work damage	<b>↓</b>	
US Sei	rvice 3	<u>↓</u>	Engine compartment  Engine - oil and filter change  every 2 years:  Check bodywork for paint work damage by service advisor  Underside of vehicle  Chassis and load-bearing body compo-	<b>↓</b>	
US Sei	rvice 3		Engine compartment  Engine - oil and filter change  every 2 years:  Check bodywork for paint work damage by service advisor  Underside of vehicle	<b>↓</b>	AP98.00-P-9850BA
US Sei	rvice 3		Engine compartment  Engine - oil and filter change  every 2 years:  Check bodywork for paint work damage by service advisor  Underside of vehicle  Chassis and load-bearing body components: Check for damage and corrosion	<b>↓</b>	AP98.00-P-9850BA
US Sei	rvice 3		Engine compartment  Engine - oil and filter change  every 2 years:  Check bodywork for paint work damage by service advisor  Underside of vehicle  Chassis and load-bearing body components: Check for damage and corrosion by service advisor	<b>↓</b>	AP98.00-P-9850BA
US Sei	rvice 3		Engine compartment  Engine - oil and filter change  every 2 years:  Check bodywork for paint work damage by service advisor  Underside of vehicle  Chassis and load-bearing body components: Check for damage and corrosion by service advisor  Engine compartment	<b>↓</b>	AP98.00-P-9850BA AP00.20-P-0090BA
US Sei	rvice 3		Engine compartment  Engine - oil and filter change  every 2 years:  Check bodywork for paint work damage by service advisor  Underside of vehicle  Chassis and load-bearing body components: Check for damage and corrosion by service advisor  Engine compartment  Replace brake fluid	<b>↓</b>	AP98.00-P-9850BA AP00.20-P-0090BA
US Sei	rvice 3		Engine compartment  Engine - oil and filter change  every 2 years:  Check bodywork for paint work damage by service advisor  Underside of vehicle  Chassis and load-bearing body components: Check for damage and corrosion by service advisor  Engine compartment  Replace brake fluid  every 26,000 mi or 2 years:	<b>↓</b>	AP98.00-P-9850BA AP00.20-P-0090BA
US Sei	rvice 4		Engine compartment  Engine - oil and filter change  every 2 years:  Check bodywork for paint work damage by service advisor  Underside of vehicle  Chassis and load-bearing body components: Check for damage and corrosion by service advisor  Engine compartment  Replace brake fluid  every 26,000 mi or 2 years:  Passenger compartment	<b>↓</b>	AP98.00-P-9850BA  AP00.20-P-0090BA  AP42.00-P-4280V
US Sei	rvice 4		Engine compartment  Engine - oil and filter change  every 2 years:  Check bodywork for paint work damage by service advisor  Underside of vehicle  Chassis and load-bearing body components: Check for damage and corrosion by service advisor  Engine compartment  Replace brake fluid  every 26,000 mi or 2 years:  Passenger compartment  Replace combination filter	<b>↓</b>	AP98.00-P-9850BA  AP00.20-P-0090BA  AP42.00-P-4280V
US Sei	rvice 4 rvice 5		Engine compartment  Engine - oil and filter change  every 2 years:  Check bodywork for paint work damage by service advisor  Underside of vehicle  Chassis and load-bearing body components: Check for damage and corrosion by service advisor  Engine compartment  Replace brake fluid  every 26,000 mi or 2 years:  Passenger compartment  Replace combination filter  not applicable	<b>↓</b>	AP98.00-P-9850BA  AP00.20-P-0090BA  AP42.00-P-4280V
US Sei	rvice 4 rvice 5		Engine compartment  Engine - oil and filter change  every 2 years:  Check bodywork for paint work damage by service advisor  Underside of vehicle  Chassis and load-bearing body components: Check for damage and corrosion by service advisor  Engine compartment  Replace brake fluid  every 26,000 mi or 2 years:  Passenger compartment  Replace combination filter  not applicable  every 52,000 mi or 5 years:	<b>↓</b>	AP98.00-P-9850BA  AP00.20-P-0090BA  AP42.00-P-4280V

Completed ⊠		Not OK			
	<b>1</b>			<b>1</b>	
US Service 11		every 65,000 mi or 5 years:			
		Engine compartment			
		Replace fuel filter			AP47.20-P-0780V
US Service 12		every 78,000 mi or 5 years:			
		Engine compartment			
		Replace spark plugs			AP15.10-P-1580VA
US Service 13		every 143,000 mi or 15 years:			
		Engine compartment			
		Replace coolant			AP20.00-P-2080V
		Vehicle over 143,000 mi:			
		Check if all fluid levels and changes are updated			
<b>⊯</b> AP		Transmission			
<b>⊯</b> AP		Rear axle			
		Check if air, fuel, ventilation filters are updated			
FFAP		Engine air filter			
FFAP		Fuel filter			
FAP		Combination filter			
		Check integrity of engine, mechanical comonents			
⊯AP		Perform compression test (hot and cold) Refer to BE01.00-Z-9999AZ			
<b>⊯</b> AP		Perform leak down test (hot and cold)			AP00.20-P-0053V
FFAP		Check spark plugs			
FAP		Exhaust system hangers and leaks			
		Check damaged / worn drivetrain parts			
<b>⊯</b> AP		Front wheel bearing play			
<b>⊯</b> AP		Rear wheel bearing play			
<b>⊯</b> AP		Axles joint play			
⊯ AP		Flexible discs			
I≆AP		Tie rod and drag link joints			